

Desktop Assy: 99-1395
Rack Assy: 99-1396

Parts Common to both assemblies

Install kit: 76-1395

Documentation: 71-1395

Power Supply: 50-22

Line Cord: 30-13

D-Sub Connector: 15-868

D-sub Cover: 17-186

MOD IV pins: 15-938-1

MOD IV 3-pin housing: 14-482

MOD IV 6-pin housing: 14-484

MOD IV 12-pin housing: 14-490

MOD IV 14-pin housing: 14-492

Cables

Headphone Jack cable: 90-1872-5

D-Sub Connector cable: 90-1741


6-Conductor Flex cable: 19-62

14-pin IDC to IDC cable: 90-1740


Hardware

4-40 x .75" panhead screw: 38-129A

Note: The first thirty SMXd mixers shipped used VSDM PCAs. All others used SMXd PCAs. The parts shown on these ID pages are only for use on rev B or later builds. They are not compatible with the first build of mixers using the VSDM PCAs.




First build units have vertically-oriented analog connectors.



Rev B and later builds have horizontally-oriented analog connectors.

Desktop Version (99-1395)



*** Component parts lists on page 2**

Rack Version (99-1396)

